

+ ARKAN / -

# START UP PROCEDURE FOR SUNGROW INVERTER



**STEP 1 -** Take a look at the AC Switch inside the switchboard - Labelled **MAIN SWITCH (INVERTER SUPPLY)** or **SOLAR SUPPLY MAIN SWITCH**. Please make sure this is in the **DOWN/OFF** Position before you start the steps below.

**STEP 2 -** Turn the DC Isolator ON - This is found next to the solar inverter - this should be in the OFF Position. Turn this to the ON Position.

**STEP 3 -** Turn the AC Isolator ON - This is also found next to the solar inverter - this should be in the OFF Position. Turn this to the ON Position.

*If your inverter is located next to your meter box, there will be NO AC Isolator to turn on.*

### **If you have a Sungrow Premium Inverter**

You may not have a DC Isolator switch located next to your inverter. Instead, the DC Isolator will be located on the bottom side of the inverter, make sure the red switch is in the ON Position.

Lastly, turn ON the AC Switch inside the switchboard - Labelled **MAIN SWITCH (INVERTER SUPPLY)** or **SOLAR SUPPLY MAIN SWITCH**.

